

How to install Cork flooring with WAKOL D 3540 Cork Flooring Adhesive



1. Start with a smooth level and dust free cement based subfloor.



2. Apply adhesive with a short-nap roller on cork backing.



3. Apply a thin layer of adhesive to the back side of the cork. Ensure full coverage but avoid adhesive puddles.



4. Apply adhesive with short-nap roller on the subfloor.



5. Apply a thin layer of adhesive to the subfloor. Ensure full coverage but avoid adhesive puddles.



6. Wait until both adhesive films are completely dry and transparent.



7. Install cork tiles by using a rubber mallet to ensure a proper bond between the two adhesive layers.



8. Install further cork tiles by using a rubber mallet.

The variety of materials used and the different construction site conditions, which be beyond our control, preclude any claims based on this data. We therefore recommend making sufficient trails. Accompanying recommendations and regulations, flooring manufacturer's instructions and the current applicable codes must be observed. Please observe our usage advice in the Technical Information of our products. We gladly provide technical advice and written installing recommendations for concrete job sites. This recommendation supersedes all previous versions.